



SYDNEY

HONG KONG

CAPE TOWN

LONDON

NEW YORK



HOW TO CHANGE TIME ON YOUR HANDSETS

NEC

- Hang up the Phone
- Press "Speaker" and then 728
- Enter the time in 24-hour format
(Example: to change time to 10:35 am press 1035)
- Time will be saved automatically